



V31S00583-020

GSM-FV TECHNICAL CHARACTERISTICS

- Power supply: 12V AC from TRMC 10/12 as shown in the diagram
- Absorption: 100mA max
- Output
 - two bistable relays with change-over contact
 - power circuit breaker: 8(5)A / 250V AC
- Signalling LEDs:
 - Two red leds for output relay status signalling
 - Two green leds for digital input status signalling
 - Multicolour leds for device status signalling
- GSM Quad Band module (900-950-1800-1900 MHz)
- SMA-F connector for external antenna provided with 3 m long cable
- Working conditions: 0-50 °C / 10-90% non-condensing
- Degree of protection: IP40
- Insulation class: II
- Container: 4 DIN modules
- Backup battery capacity: approximately 1 hour

GSM-FV DEVICE STATUS

The device status is signalled by the led \uparrow :

- SWITCHED OFF \rightarrow no power supply to device
 - RED BLINKING \rightarrow sim card not inserted or pin active
 - RED STEADY \rightarrow insufficient gm field
 - GREEN STEADY \rightarrow initialising instrument/network search
 - GREEN BLINKING \rightarrow gsm network connection
 - GREEN BLINKING VELOCE \rightarrow command (ring tone or text message) incoming
 - GREEN/RED BLINKING \rightarrow active programming mode
 - YELLOW BLINKING \rightarrow gsm network connection but battery flat
 - QUICKLY BLINKING RED \rightarrow modem error or failure (if still flashing)
- Note: blinking = 1 lamp / second
quickly blinking = 5 lamps / second

User manual GSM COMMUNICATION INTERFACE

Read all instructions carefully

- GSM-FV** is a system for the remote control of photovoltaic systems by sending text messages or ring tones to certified users. The heart of the system is made up of GSM-FV which compares the signal coming from the produced energy meter on the system and that coming from the radiation sensor to check if production complies with the radiation conditions, thus enabling any malfunctions to be found in time. Any fall in production is automatically communicated by the system by sending text messages to the selected users. Furthermore, GSM-FV has another input available for connecting a burglar alarm and two outputs which can be activated manually or following an alarm.

SAFETY WARNINGS

- During the installation and operation of the device observe the following instructions:*
- The instrument must be installed by a qualified person**
 - The instrument must be installed and activated in compliance with current electric systems standards**
 - After installation, inaccessibility to the connection terminals without appropriate tools must be granted**
 - Do not use the instrument for purposes other than indicated**
 - The device must be installed in a electric closed panel well protected**
 - A two-pole disconnect device shall be provided as part of the building installation**
 - A protection device against over-currents should be installed in the electrical system, upstream of the device**
 - Carefully respect the wiring diagrams to install the instrument**
 - Before accessing the connection terminals, verify that the leads are not live**
 - Do not power or connect the instrument if any part of it is damaged**
 - The use of a GSM device can cause interference with the functioning of electronic devices non-screened from radiofrequency signals (electromedical devices, pacemakers, hearing aids etc.)**
 - In case of fault, do not service the device yourself but contact the after-sales service**
 - The instrument is aimed for use in place with measurement category III and pollution degree 2, as per standards EN 61010-1.**

Model Description	
KIT SOLARGEST MONOFÁSICO	Kit telecontrol for single-phase systems up to 15 kW
KIT SOLARGEST TRIFÁSICO DIRECTA	Kit telecontrol for three-phase systems up to 69 kW
KIT SOLARGEST TRIFÁSICO INDIRECTA	Kit telecontrol for three-phase systems up to 690 kW

The kit solargest is made up of:


- GSM-FV** control unit
- radiation sensor
- TRMC 10/12** transformer (code OB86C1012)
- ANRET M-63** energy meter (code 540002) (single-phase systems) or **CONTAX D-9073** (code OB708400) (three-phase 69kW systems) or **CONTAX 0643i** (code OB708800) (three-phase 690kW systems)

INSTALLATION

Preparation

Disable the pin code request from the sim card which will be inserted into the GSM-FV.

Insert the sim card into the slot (type push-push). The direction of insertion provides that the bevel of the sim card goes inside in the left.



Note: the rechargeable sim needs a periodical minimum top-up (usually once a year) in order to be valid. Check with your operator about the renewal mode.

Note. The sim card insertion and removal operations should be carried out with the instrument switched off and not powered up (please see the relative chapter for switching off the instrument).

Wiring

- Attach the radiation sensor near the photovoltaic panels with the same inclination and connect it to the analog input of the GSM-FV (the white/black wire to terminal 14, the black one to terminal I2).
- Caution: the sensor must be positioned so that the solar rays do not hit it before they hit the panels, in order to avoid false alarms being sent, for example, at dawn.
- connect the energy meter down from the solar production inverter, and connect the pulse output meter at input 1 of the GSM-FV (DIG1 - terminals 10 and 13)
- connect any burglar system (presence sensors, microswitches, ...) at digital input 2 GSM-FV (DIG2 - terminals 11 and 13)
- connect the transformer to the GSM-FV and the network voltage.

For a detailed description of the connections, please see the diagram "Connection diagram".

Once the kit has been powered up, the led \uparrow of the GSM-FV relating to the device status will remain on steady green for around 30 seconds, this will end when it starts blinking green once a second, signalling the correct reception of the gsm network. If this should not be the case, please see the overview "Device status".

Basic configuration

Consists in defining the admin number, which has full control of the system (usually for the owner) to whom alarm messages are sent

MEMORISING ADMINISTRATIVE NUMBERS

- press the "1" key of the GSM-FV for 5 seconds until the led \uparrow starts blinking red/green alternately
- carry out a ring tone with the number which you want to set as admin number.
- The caller will receive a confirmation text message that this has taken place.

Note: after having set the admin number, the GSM-FV will carry out a self-calibration procedure, during which time it analyses all the parameters of the system where it is installed. To carry out this operation the GSM-FV needs a few hours of sunshine. At the end, the admin number will receive a text message and from then on, it will begin to monitor the produced energy.

OPERATION

Default settings

- The factory settings for the kit provide for the admin number to receive a series of text messages:
- send a monthly text message to the administrator with the value of produced energy
 - send a text message containing the value of produced energy and instantaneous power following a ring tone
 - forward messages destined to the GSM-FV and not recognisable as commands (for example a text message from a telephone service provider) to the administrator

Furthermore a text message is sent to the administrator in cases of:

- radiation sensor malfunction alarm
 - no meter pulses alarm
 - production below threshold alarm
 - no electrical network or buffer battery flat alarm
- For each of the alarms listed above, an alarm return text message is sent.

By default the pulse weight received from input DIG1 is 0.1 kWh (modifiable).

Advanced configuration

In this phase it is possible to add other telephone numbers as well as the administrator's (staff numbers) where alarm signals will be sent, by choosing for each number which type of alarm to send. Furthermore, it is possible to modify the automatic forwarding plan for messages with planned set times or activate automatic switching function for an output following a specific alarm condition.

STRUCTURE OF A COMMAND TEXT MESSAGE

The general structure of a text message is as follows:

[password] [separator] [command] [separator] [parameter1] [separator]...[parameterNo.] where:

- [password] \rightarrow numerical field of a maximum of 8 figures
- [separator] \rightarrow comprised of one or more space characters
- [command] \rightarrow command recognised by the device
- [parameter..] \rightarrow series of parameters relative to the command

The password field may be omitted if the command is given by a registered number. Several commands may be included in one text message. In this case, the

commands executed will only be those whose reply is contained in a standard text message (160 characters). To enter numbers with the decimal separator, you need to use a full stop.

The structure of a reply to a command is similar to the command itself, with the addition of the "=" symbol to indicate the current status. For example:

OUTKEY BLOCK \rightarrow OUTKEY=BLOCK

MODIFY PULSE WEIGHTS (for admin only)

By default the pulse weight that the GSM-FV receives from the energy meter is 0.1 kWh. If it is necessary to modify this value use the command:

WIMP [pulse weight] where

[pulse weight] \rightarrow new value to be given to a pulse

In the case of decimal values, use a decimal point as a separator. To read the current value use the command WIMP with no parameters.

For example:
WIMP 1 gives the value 1.00 kWh to each pulse
WIMP 0.1 gives the value 0.10 kWh to each pulse
WIMP restores the current weight of the pulse

MEMORISING STAFF NUMBERS (for admin only)

- It is possible to create a telephone book containing up to 10 telephone numbers (staff numbers) which can:
- receive text message (or ring tone) in case of alarms
 - receive text message with the produced energy and the instantaneous power following a ring tone
 - receive text message following a scheduled event.

The staff numbers are identified progressively from 1 to 10. The first 5 staff numbers are already associated by default to 5 well defined alarm situations (please see "Alarms management") even if they can be modified.

To add a staff number:

- send the following command from the admin number:

STAFF [index] [telephone number] where,

[index] \rightarrow position in the staff telephone book where the new number is saved
[telephone number] \rightarrow number to be added to the telephone book

For example, to insert the staff number 392123445 in position 4:
STAFF 4 392123445

It is also possible to enter several staff numbers using one command only: For example, if you want to insert the numbers 044177458, 392123445 and 12345678 in positions 2, 4, and 7:
STAFF 2 044177458 4 392123445 7 12345678

To cancel a staff number, use the word NULL. For example, if you want to cancel the staff number 4, leaving the position in the telephone book empty:
STAFF 4 null

To have a complete overview of the telephone book write STAFF without parameters.

Note: the admin number is inserted by default as staff number position 1.

ALARMS MANAGEMENT

The possible alarm sources are reported in the following table:

Type of alarm	Alarm description
DIG2	Alarm from digital input 2
RDIG2	Alarm return from digital input 2
LOWBAT	Low battery alarm
POWERF	No network alarm
RPOWERF	Alarm return for no mains
SCHED	Message for periodic forwarding
LUX	Radiation sensor malfunction
RLUX	Alarm return radiation sensor
IMP	Inverter malfunction
RIMP	Alarm return inverter malfunction
DELTA	Alarm energy production lower than predicted
RDELTA	Alarm return energy production
POK	Production exceeds the threshold defined with SETPOK
RPOK	Alarm return energy production above the threshold

It is possible to define which types of alarms are sent to each staff number and in which format (text message or ring tone). The first 5 staff numbers are set as follows:

